Safety precautions

- Keep all surrounding areas dry.
- Don't place the Waxifyer in water, or pour water into the Waxifyer.
- Place the Waxifyer on a flat surface.
- Keep the Waxifyer out of reach of children and pets.
- Unplug the Waxifyer when not in use, allow to cool down completely before handling, cleaning or storing.
- If abnormal temperatures occur while in use, immediately unplug the Waxifyer.

Make sure to never operate your Waxifyer if:

- The cord is damaged
- The Waxifyer is malfunctioning
- The Waxifyer was dropped or damaged
- The Waxifyer was dropped in water

If the power cord is damaged, it must be replaced by the manufacturer, service agent, or a qualified professional to avoid hazards.

Take precautions during maintenance, following all safety guidelines.

Specifications

Model: WAXIFYER DY-119 Input: 220 - 240V 50/60 Hz

Power: 100 W (Max)

Plug: EU



Designed in the Netherlands | Made in China | Dynamic Bike Care B.V. Lulofsstraat 55 Unit 25 | 2521 AL | The Hague | NL | +31 (0) 85 022 03 62 www.dynamicbikecare.com | info@dynamicbikecare.com



WAXIFYER

PREMIUM HOT WAX HEATER



Please read this manual carefully before use. Keep manual for future reference.

Waxifyer premium hot wax heater

The Dynamic Waxifyer is a premium hot wax heater designed for use with Hyper and Wander Wax and fully compatible with all other kinds of hot wax. With a powerful 100W heating system with electronic thermostat, it delivers consistent and precise heat, ensuring optimal waxing of your chain.

The adjustable temperature range from 50°C to 135°C allows you to wax efficiently in any condition, getting the job done quickly and effectively. A vented, see-through cover lets you monitor the melting process without releasing valuable heat. CE certified and backed by a 2-year warranty, the Dynamic Waxifyer guarantees reliable and professional results every time.

Instructions for use

- 1. Remove all packaging materials.
- 2. Place the hot wax in the Waxifyer, break the wax into smaller pieces to ensure quick melting. Place the see-through vented cover on the Waxifyer while melting the hot wax.
- 3. Turn the temperature control knob to 'perfect'.
- 4. If you're working in a cold environment or want to give the melting process an extra boost: turn the temperature knob to 'extra hot'. Make sure to turn back to 'perfect' once the hot wax is liquid.
- 5. While waiting for the hot wax to melt, make sure to clean and dry the chain thoroughly.
- 6. Place the clean chain in the liquid hot wax for at least 15 minutes.
- 7. Take the chain out of the hot wax and let the excess drip off.
- 8. Turn off the Waxifyer. Leave the hot wax to solidify in the Waxifyer.

Instructions are provided to ensure safe use of the appliance.

This appliance is suitable for children aged 8+ and persons with reduced physical, sensory, or mental capabilities if supervised or instructed on safe use. Children must not play with the appliance. Cleaning and maintenance require adult supervision.

Waxifyer temperature range

The Waxifyer packs 100 Watts of heating power, with an adjustable electronic thermostat. The Waxifyer has a temperature range of 50°C – 135°C. The Waxifyer was developed for use with Dynamic Wander Wax and Hyper Hot Wax, maintaining the ideal temperature of 70°C – 80°C when set to 'perfect'.

Waxifyer features

- See-through vented cover: allowing for easy monitoring of the melting process while containing heat.
- 600 ml capacity: easily fits three portions/bars of Hyper or Wander Wax (240 g) and an entire chain.
- Developed for use with Hyper or Wander Wax, suitable for all types of hot wax.

Indicator light

If you turn the Waxifyer on, the red indicator light will turn on. Once the heating element of the Waxifyer has reached the desired temperature the light will turn off. If the temperature drops, the heating element will turn on again together with the indicator light.

You can find this manual and a detailed step by step guide of hot waxing your chain in NL, DE, EN and FR via this QR code. \rightarrow





